

Cancel

切
取消

Non-rinse rice
Brown rice (germinated)

無洗米
発芽玄米

Cooking Speed Keep Warm Timer

Timer1 予約1 予約2 Timer2
28:88

a. b. c. d.
パン発酵 焼き・蒸し 温泉卵 豆腐

a. Bread fermentation
b. Grill/Steam
c. Poached Egg
d. Tofu

Start

*Press twice for
Speed mode

おかゆ

Porridge

予約

Timer

時

Hours

分

Min

メニュー

Menu

How to cook rice:

1. Measure rice in the attached cup (1 cup = 180ml)
2. Rinse rice until water becomes clear in pot
3. Fill in water (proportionate to amount of rice)
4. Insert pot into rice cooker / close lid
5. (Optional) Customize program or set timer
6. Press start

