



# Microwave Oven

## MRO-TT5



MICROWAVE | TOASTER/GRILL | OVEN

### AUTOMATIC

To use **automatic microwave** function:

1. Place food in the microwave
2. Press start

※This function is used for rice & side dishes only

To use **select menu** and **quick access microwave** function:

1. Place food in the microwave
2. Press the designated button for that food
3. Press start

※In **select menu**, the menu will change each time you press

To use **microwave function manually:**

1. Place food in the microwave
2. Press Microwave button
3. Set the time using the designated time buttons
4. Press start

To use **oven without pre-heat:**

1. Place food in the oven and press oven button 2 times
2. Adjust the temperature using the  $\wedge$  and  $\vee$  buttons
3. Set the time using the designated time buttons
4. Press start

To **ferment using oven function:**

1. Place food in the microwave
2. Press oven button 2 times
3. Adjust the temperature using the  $\wedge$  and  $\vee$  buttons
4. Set the time using the designated time buttons and press start

※Press Microwave button several times to adjust power input

※Press designated time buttons several times to add up time

To use **Toaster/Grill** function:

1. Press Toaster/Grill button
2. Set the time using the designated time buttons
3. Press start

To use **oven with pre-heat:**

1. Press oven button 1 time
2. Adjust the temperature using the  $\wedge$  and  $\vee$  buttons
3. Set the time using the designated time buttons
4. Press start and wait until the sound goes off
5. Place food in the microwave and press start

To **ferment using microwave function:**

1. Place food in the microwave
2. Press microwave button 5 times
3. Set the time using the designated time buttons
4. Press start

<u>Daily food/Confectionary</u>		<u>10 minutes menu</u>	<u>Non-fry</u>
6. Heat up frozen food	12. Fried noodles	18. 10 minutes stewed food	20. Fried chicken
7. Defrost	13. Frozen noodles	19. 10 minutes steamed food	21. Pork cutlet
8. Brief defrost	14. Heat up fried food		22. Fried prawn
9. Vegetables	15. Gratin		23. Fried fish
10. Root vegetables	16. Sweets		24. Croquette
11. Sake	17. Sponge cake		

デイリー/お菓子			10分メニュー	ノンフライ		
6 解凍あたため	9 葉・果菜	12 焼きそば	15 グラタン	18 10分煮物	20 鶏のから揚げ	23 あじフライ
7 解凍	10 根菜	13 冷凍めん	16 お菓子	19 10分蒸し物	21 とんカツ	24 コロケ
8 半解凍	11 酒かん	14 フライあたため	17 スポンジケーキ		22 えびフライ	